

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		AC DIGITAL POSITIONERS						DC DIGITAL POSITIONERS			
		STANDARD						STANDARD			
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						Command Signal 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)			
Actuator Model	Power Source	Feedback Signal None	Feedback Signal mA VDC	Feedback Signal mA VDC Aux Close Aux Open Fault Relays	Feedback Signal 4-20mA (2-wire) Isolated	Feedback Signal 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	Feedback Signal Modbus	Feedback Signal None	Feedback Signal 4-20mA (2-wire) Isolated	Feedback Signal 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	Feedback Signal Modbus
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-003 S70-006	24VDC	_____	_____	_____	_____	_____	_____	DHC-400 MKT-157 POT-102	DHC-400 MKT-157 POT-102 OTX-101	DHC-400 MKT-157 POT-102 OTR-101	DHC-400 MKT-157 POT-102 OCM-102
	24VAC	ADM-100C DHC-100B MKT-157 POT-102 EXE-100 (2) EEF-100 (3)	ADM-100C DHC-100B MKT-157 POT-102 EXE-100 (2) EEF-100 OTX-100 (3)	ADM-100C DHC-100B MKT-157 POT-102 EXE-100 (2) EEF-100 OTR-100 (3)	ADM-100C DHC-100B MKT-157 POT-102 EXE-100 (2) EEF-100 OTX-101 (3)	ADM-100C DHC-100B MKT-157 POT-102 EXE-100 (2) EEF-100 OTR-101 (3)	ADM-100C DHC-100B MKT-157 POT-102 EXE-100 (2) EEF-100 OCM-102 (3)	_____	_____	_____	_____
	120VAC	DHC-100 MKT-157 POT-102	DHC-100 MKT-157 POT-102 OTX-100	DHC-100 MKT-157 POT-102 OTR-100	DHC-100 MKT-157 POT-102 OTX-101	DHC-100 MKT-157 POT-102 OTR-101	DHC-100 MKT-157 POT-102 OCM-102	_____	_____	_____	_____
	220VAC	DHC-100A MKT-157 POT-102	DHC-100A MKT-157 POT-102 OTX-100	DHC-100A MKT-157 POT-102 OTR-100	DHC-100A MKT-157 POT-102 OTX-101	DHC-100A MKT-157 POT-102 OTR-101	DHC-100A MKT-157 POT-102 OCM-102	_____	_____	_____	_____

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		AC ANALOG POSITIONERS											
		STANDARD						MINIATURE					
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-003 S70-006	24VDC	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
	24VAC	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	120VAC	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	220VAC	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		AC LOG RATE POSITIONERS			DC ANALOG POSITIONERS					
		STANDARD			STANDARD				MINIATURE	
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			Command Signal 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				Command Signal 4-20mA Only	
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	without Current Trip		with Current Trip		without Current Trip	
					Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal None	Feedback Signal 4-20mA
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-003 S70-006	24VDC	_____	_____	_____	DMC-102 MKT-157 POT-102	DMC-102 MKT-157 POT-102 XMA-105 (1)	DMC-102A MKT-157 POT-102	DMC-102A MKT-157 POT-102 XMA-105 (1)	N/A	N/A
	24VAC	N/A	N/A	N/A	_____	_____	_____	_____	_____	_____
	120VAC	N/A	N/A	N/A	_____	_____	_____	_____	_____	_____
	220VAC	N/A	N/A	N/A	_____	_____	_____	_____	_____	_____

BRAY (See General Notes and Footnotes on Page 15)		ON/OFF APPLICATIONS						TIMER ONLY APPLICATIONS		
		STANDARD							MINIATURE	
		Control Signal 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			Control Signal Switch Relay Open Collector with Adjustable Current Trip				AC Sequence Timers	DC Sequence Timers
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 1-5mA	AC or DC Motor Converter Module	AC Repeat Cycle Timers		
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts			Order Parts	Order Parts
S70-003 S70-006	24VDC	_____	_____	_____	RCM-101A MKT-157	RCM-101C MKT-157 POT-102	ADM-100C MKT-157	_____	_____	DST-100A MKT-157
	24VAC	ADM-100C AMI-103B MKT-157 EXE-100 (2) EEF-100 (3)	ADM-100C AMI-103B MKT-157 POT-102 EXE-100 (2) EEF-100 XMA-105 (3)	ADM-100C AMI-103B MKT-157 POT-102 EXE-100 (2) EEF-100 XMA-106 (3)	_____	_____	ADM-100C MKT-157 (3)	ADM-100C MKT-157 RCT-100B (3)	N/A	_____
	120VAC	AMI-103 MKT-157	AMI-103 MKT-157 POT-102 XMA-105	AMI-103 MKT-157 POT-102 XMA-106	_____	_____	_____	RCT-100	AST-100 MKT-157	_____
	220VAC	AMI-103A MKT-157	AMI-103A MKT-157 POT-102 XMA-105	AMI-103A MKT-157 POT-102 XMA-106	_____	_____	_____	RCT-100A	AST-100A MKT-157	_____

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		FEEDBACK SIGNAL ONLY APPLICATIONS					
		1K Ohm Feedback Pot Only	4-20mA Feedback (2-wire)	4-20mA Feedback (3-wire)	4-20mA Feedback Powered	0-5V 0-10V Feedback (3-wire)	0-5V 0-10V Feedback Powered
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-003 S70-006	24VDC	MKT-157 POT-102 (2)	MKT-157 POT-102 XMA-107	MKT-157 POT-102 XMA-105	_____	MKT-157 POT-102 XMA-106	_____
	24VAC	MKT-157 POT-102 (2)	MKT-157 POT-102 XMA-107	MKT-157 POT-102 XMA-105	N/A	MKT-157 POT-102 XMA-106	N/A
	120VAC	MKT-157 POT-102 (2)	MKT-157 POT-102 XMA-107	MKT-157 POT-102 XMA-105	MKT-157 POT-102 XMA-105 PWR-102	MKT-157 POT-102 XMA-106	MKT-157 POT-102 XMA-106 PWR-102
	220VAC	MKT-157 POT-102 (2)	MKT-157 POT-102 XMA-107	MKT-157 POT-102 XMA-105	MKT-157 POT-102 XMA-105 PWR-102A	MKT-157 POT-102 XMA-106	MKT-157 POT-102 XMA-106 PWR-102A

BRAY (See General Notes and Footnotes on Page 15)		AC DIGITAL POSITIONERS						DC DIGITAL POSITIONERS			
		STANDARD						STANDARD			
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						Command Signal 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)			
Actuator Model	Power Source	Feedback Signal None	Feedback Signal mA VDC	Feedback Signal mA VDC Aux Close Aux Open Fault Relays	Feedback Signal 4-20mA (2-wire) Isolated	Feedback Signal 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	Feedback Signal Modbus	Feedback Signal None	Feedback Signal 4-20mA (2-wire) Isolated	Feedback Signal 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	Feedback Signal Modbus
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-008 S70-012 S70-020 S70-030 S70-050 S70-065 S70-708 S70-712 S70-720	24VDC	_____	_____	_____	_____	_____	_____	DHC-400 MKT-158 POT-102	DHC-400 MKT-158 POT-102 OTX-101	DHC-400 MKT-158 POT-102 OTR-101	DHC-400 MKT-158 POT-102 OCM-102
	24VAC	ADM-100C DHC-100B MKT-158 POT-102 POT-102 (3)	ADM-100C DHC-100B MKT-158 POT-102 OTX-100 (3)	ADM-100C DHC-100B MKT-158 POT-102 OTR-100 (3)	ADM-100C DHC-100B MKT-158 POT-102 OTX-101 (3)	ADM-100C DHC-100B MKT-158 POT-102 OTR-101 (3)	ADM-100C DHC-100B MKT-158 POT-102 OCM-102 (3)	_____	_____	_____	_____
	120VAC	DHC-100 MKT-158 POT-102	DHC-100 MKT-158 POT-102 OTX-100	DHC-100 MKT-158 POT-102 OTR-100	DHC-100 MKT-158 POT-102 OTX-101	DHC-100 MKT-158 POT-102 OTR-101	DHC-100 MKT-158 POT-102 OCM-102	_____	_____	_____	_____
	220VAC	DHC-100A MKT-158 POT-102	DHC-100A MKT-158 POT-102 OTX-100	DHC-100A MKT-158 POT-102 OTR-100	DHC-100A MKT-158 POT-102 OTX-101	DHC-100A MKT-158 POT-102 OTR-101	DHC-100A MKT-158 POT-102 OCM-102	_____	_____	_____	_____

BRAY (See General Notes and Footnotes on Page 15)		AC ANALOG POSITIONERS											
		STANDARD						MINIATURE					
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-008 S70-012 S70-020 S70-030 S70-050 S70-065 S70-708 S70-712 S70-720	24VDC	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
	24VAC	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	120VAC	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	220VAC	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		AC LOG RATE POSITIONERS			DC ANALOG POSITIONERS					
		STANDARD			STANDARD				MINIATURE	
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			Command Signal 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				Command Signal 4-20mA Only	
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	without Current Trip		with Current Trip		without Current Trip	
					Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal None	Feedback Signal 4-20mA
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-008 S70-012 S70-020 S70-030 S70-050 S70-065 S70-708 S70-712 S70-720	24VDC	_____	_____	_____	DMC-102 MKT-158 POT-102	DMC-102 MKT-158 POT-102 XMA-105 (1)	DMC-102A MKT-158 POT-102	DMC-102A MKT-158 POT-102 XMA-105 (1)	N/A	N/A
	24VAC	N/A	N/A	N/A	_____	_____	_____	_____	_____	_____
	120VAC	N/A	N/A	N/A	_____	_____	_____	_____	_____	_____
	220VAC	N/A	N/A	N/A	_____	_____	_____	_____	_____	_____

BRAY (See General Notes and Footnotes on Page 15)		ON/OFF APPLICATIONS						TIMER ONLY APPLICATIONS		
		STANDARD							MINIATURE	
		Control Signal 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			Control Signal Switch Relay Open Collector with Adjustable Current Trip				AC Repeat Cycle Timers	AC Sequence Timers
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 1-5mA	AC or DC Motor Converter Module			
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts			Order Parts	Order Parts
S70-008 S70-012 S70-020 S70-030 S70-050 S70-065 S70-708 S70-712 S70-720	24VDC	_____	_____	_____	N/A	N/A	ADM-100C MKT-158	_____	_____	N/A
	24VAC	ADM-100C AMI-103B MKT-158 (3)	ADM-100C AMI-103B MKT-158 POT-102 XMA-105 (3)	ADM-100C AMI-103B MKT-158 POT-102 XMA-106 (3)	_____	_____	ADM-100C MKT-158 (3)	ADM-100C MKT-158 RCT-100B (3)	N/A	_____
	120VAC	AMI-103 MKT-158	AMI-103 MKT-158 POT-102 XMA-105	AMI-103 MKT-158 POT-102 XMA-106	_____	_____	_____	_____	AST-100 MKT-158 (4)	_____
	220VAC	AMI-103A MKT-158	AMI-103A MKT-158 POT-102 XMA-105	AMI-103A MKT-158 POT-102 XMA-106	_____	_____	_____	_____	AST-100A MKT-158	_____

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		FEEDBACK SIGNAL ONLY APPLICATIONS					
		1K Ohm Feedback Pot Only	4-20mA Feedback (2-wire)	4-20mA Feedback (3-wire)	4-20mA Feedback Powered	0-5V 0-10V Feedback (3-wire)	0-5V 0-10V Feedback Powered
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-008 S70-012 S70-020 S70-030 S70-050 S70-065 S70-708 S70-712 S70-720	24VDC	MKT-158 POT-102 (2)	MKT-158 POT-102 XMA-107	MKT-158 POT-102 XMA-105	_____	MKT-158 POT-102 XMA-106	_____
	24VAC	MKT-158 POT-102 (2)	MKT-158 POT-102 XMA-107	MKT-158 POT-102 XMA-105	N/A	MKT-158 POT-102 XMA-106	N/A
	120VAC	MKT-158 POT-102 (2)	MKT-158 POT-102 XMA-107	MKT-158 POT-102 XMA-105	MKT-158 POT-102 XMA-105 PWR-102	MKT-158 POT-102 XMA-106	MKT-158 POT-102 XMA-106 PWR-102
	220VAC	MKT-158 POT-102 (2)	MKT-158 POT-102 XMA-107	MKT-158 POT-102 XMA-105	MKT-158 POT-102 XMA-105 PWR-102A	MKT-158 POT-102 XMA-106	MKT-158 POT-102 XMA-106 PWR-102A

BRAY (See General Notes and Footnotes on Page 15)		AC DIGITAL POSITIONERS						DC DIGITAL POSITIONERS			
		STANDARD						STANDARD			
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						Command Signal 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)			
Actuator Model	Power Source	Feedback Signal None	Feedback Signal mA VDC	Feedback Signal mA VDC Aux Close Aux Open Fault Relays	Feedback Signal 4-20mA (2-wire) Isolated	Feedback Signal 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	Feedback Signal Modbus	Feedback Signal None	Feedback Signal 4-20mA (2-wire) Isolated	Feedback Signal 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	Feedback Signal Modbus
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-13 S70-18	120VAC	DHC-100 MKT-184 POT-102	DHC-100 MKT-184 POT-102 OTX-100	DHC-100 MKT-184 POT-102 OTR-100	DHC-100 MKT-184 POT-102 OTX-101	DHC-100 MKT-184 POT-102 OTR-101	DHC-100 MKT-184 POT-102 OCM-102	_____	_____	_____	_____
	220VAC	DHC-100A MKT-184 POT-102	DHC-100A MKT-184 POT-102 OTX-100	DHC-100A MKT-184 POT-102 OTR-100	DHC-100A MKT-184 POT-102 OTX-101	DHC-100A MKT-184 POT-102 OTR-101	DHC-100A MKT-184 POT-102 OCM-102	_____	_____	_____	_____

BRAY (See General Notes and Footnotes on Page 15)		AC ANALOG POSITIONERS											
		STANDARD						MINIATURE					
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V			Command Signal 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-13 S70-18	120VAC	AMC-101A MKT-184 POT-102	AMC-101A MKT-184 POT-102 XMA-105	AMC-101A MKT-184 POT-102 XMA-106	AMC-101A MKT-184 POT-102 RCT-100	AMC-101A MKT-184 POT-102 RCT-100 XMA-105	AMC-101A MKT-184 POT-102 RCT-100 XMA-106	N/A	N/A	N/A	N/A	N/A	N/A
	220VAC	AMC-101C MKT-184 POT-102	AMC-101C MKT-184 POT-102 XMA-105	AMC-101C MKT-184 POT-102 XMA-106	AMC-101C MKT-184 POT-102 RCT-100A	AMC-101C MKT-184 POT-102 RCT-100A XMA-105	AMC-101C MKT-184 POT-102 RCT-100A XMA-106	N/A	N/A	N/A	N/A	N/A	N/A

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		AC LOG RATE POSITIONERS			DC ANALOG POSITIONERS					
		STANDARD			STANDARD				MINIATURE	
		Command Signal 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			Command Signal 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				Command Signal 4-20mA Only	
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	without Current Trip		with Current Trip		without Current Trip	
					Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal None	Feedback Signal 4-20mA
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
S70-13 S70-18	120VAC	LRC-101A,G MKT-184 POT-102	LRC-101A,G MKT-184 POT-102 XMA-105	LRC-101A,G MKT-184 POT-102 XMA-106	_____	_____	_____	_____	_____	_____
	220VAC	LRC-101B,H MKT-184 POT-102	LRC-101B,H MKT-184 POT-102 XMA-105	LRC-101B,H MKT-184 POT-102 XMA-106	_____	_____	_____	_____	_____	_____

BRAY (See General Notes and Footnotes on Page 15)		ON/OFF APPLICATIONS						TIMER ONLY APPLICATIONS		
		STANDARD							MINIATURE	
		Control Signal 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			Control Signal Switch Relay Open Collector with Adjustable Current Trip				AC Repeat Cycle Timers	AC Sequence Timers
Actuator Model	Power Source	Feedback Signal None	Feedback Signal 4-20mA	Feedback Signal 0-5V 0-10V	Feedback Signal None	Feedback Signal 1-5mA	AC or DC Motor Converter Module			
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts			Order Parts	Order Parts
S70-13 S70-18	120VAC	AMI-103 MKT-184	AMI-103 MKT-184 POT-102 XMA-105	AMI-103 MKT-184 POT-102 XMA-106	—————	—————	—————	RCT-100	N/A	—————
	220VAC	AMI-103A MKT-184	AMI-103A MKT-184 POT-102 XMA-105	AMI-103A MKT-184 POT-102 XMA-106	—————	—————	—————	RCT-100A	N/A	—————

BRAY <i>(See General Notes and Footnotes on Page 15)</i>		FEEDBACK SIGNAL ONLY APPLICATIONS					
		1K Ohm Feedback Pot Only	4-20mA Feedback (2-wire)	4-20mA Feedback (3-wire)	4-20mA Feedback Powered	0-5V 0-10V Feedback (3-wire)	0-5V 0-10V Feedback Powered
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
Actuator Model	Power Source	MKT-184 POT-102 (2)	MKT-184 POT-102 XMA-107	MKT-184 POT-102 XMA-105	MKT-184 POT-102 XMA-105 PWR-102	MKT-184 POT-102 XMA-106	MKT-184 POT-102 XMA-106 PWR-102
		MKT-184 POT-102 (2)	MKT-184 POT-102 XMA-107	MKT-184 POT-102 XMA-105	MKT-184 POT-102 XMA-105 PWR-102A	MKT-184 POT-102 XMA-106	MKT-184 POT-102 XMA-106 PWR-102A

GENERAL NOTES

- A) MKT-157, MKT-158, and MKT-184 mounting kits allow (2) auxiliary cam switches to be added.
- B) Replace DHC-100A with DHC-100D for CE certification (see CE Declaration of Conformity 1001-6A).
- C) When specifying actuator duty cycle, it should be "continuous duty motor".

FOOTNOTES

- (1) XMA-104A will require mounting location within the actuator or externally at 135 ohm slide wire.
- (2) Feedback potentiometer field connections are terminated via potentiometer wire pigtail.
- (3) When using the ADM-100C in 24VAC applications, the Bray 24VAC Relay Card must be removed.
- (4) Not available for S70-050 and S70-065.